

Charging BTBeacons

Charging Overview

BTBeacons are charged using the BTSmart Charger. BTBeacons can be connected to the BTSmart Charger using the Mini USB port found on the side of the BTBeacon.

Attention:

- The Mini USB port of the BTBeacon is not designed to be a peripheral device to a Class B personal computer. As such, a user shall not connect the USB port to a Class B personal computer during normal operation.
- The sole power source of the BTBeacon is the internal 3.7V rechargeable Lithium-ion battery. The BTBeacon does not require a connection at the Mini USB port to operate.

To charge a BTBeacon using the BTSmart Charger

Connect the BTBeacon to the charge station via the Mini USB port found on the side of the BTBeacon.

Result: The BTBeacon is charging. To determine when the BTBeacon is fully charged, see [BTBeacon status LEDs \(During operation\)](#).
